

Robertson® mounting system for bronze

Every bronze frame (open or covered) which is NOT ordered with 3M VHB Tape or installed using epoxy should be installed with the Robertson® mounting system. This system is quick, easy and secure. Every bronze piece is shipped with the following:

- 1 – Robertson® Screwdriver (Free with FIRST order. Subsequent drivers \$1.00 ea);
- 1 – Set of brass screws (2) and PVC masonry anchors (2);

To install:

- Use the frame as a template for determining where to drill holes;
- Using a 3/16" or 7/32" masonry drill bit, carefully drill two holes into the monument;
- Insert a PVC masonry anchor into each hole (if you used a 3/16" bit, you may have to gently tap the anchor into place);
- Align frames with holes; fasten with Robertson® screwdriver, being careful not to overtighten.

If you have any questions, please call us toll-free at 1-866-810-9500.